

FORM #0034
Superlift
211 Horn Lane
West Monroe, LA. 71292
Phone: 318-322-3458
Toll Free: (Except in LA) 1-800-551-4955
FAX: 318-323-5995

INSTALLATION INSTRUCTIONS

Additional badges can be purchased directly from Superlift. Please call for more information.

We suggest putting the badges on the skid plate, Superlift bracketry, front fenders, tailgate, or rear window. The badge mounts by means of factory applied, double-backed tape. Follow these instructions to ensure that the badge sticks properly.

-Clean designated area with warm, soapy water. Rinse and wipe dry with a soft, lint free towel.

- Thoroughly prep the area with the furnished alcohol wipe pad and wipe dry with a soft, lint free towel.

NOTE: Do not touch the surface again with your hands, they transfer body oils.

-Remove mounting tape backing, line up badge, and press in place. NOTE: Do not touch mounting tape or allow tape to get dirty.

- Press firmly on the badge face and hold for a few seconds to seat mounting tape.

-A superior adhesive bond forms over time. We recommend allowing 24 hours of cure time before washing and waxing. The emblem itself can be cleaned with any glass cleaning solution.

FORM #0034
Superlift
211 Horn Lane
West Monroe, LA. 71292
Phone: 318-322-3458
Toll Free: (Except in LA) 1-800-551-4955
FAX: 318-323-5995

INSTALLATION INSTRUCTIONS

Additional badges can be purchased directly from Superlift. Please call for more information.

We suggest putting the badges on the skid plate, Superlift bracketry, front fenders, tailgate, or rear window. The badge mounts by means of factory applied, double-backed tape. Follow these instructions to ensure that the badge sticks properly.

-Clean designated area with warm, soapy water. Rinse and wipe dry with a soft, lint free towel.

- Thoroughly prep the area with the furnished alcohol wipe pad and wipe dry with a soft, lint free towel.

NOTE: Do not touch the surface again with your hands, they transfer body oils.

-Remove mounting tape backing, line up badge, and press in place. NOTE: Do not

touch mounting tape or allow tape to get dirty.

- Press firmly on the badge face and hold for a few seconds to seat mounting tape.

- A superior adhesive bond forms over time. We recommend allowing 24 hours of cure time before washing and waxing. The emblem itself can be cleaned with any glass cleaning solution.