



Slip-On Muffler Installation Instructions

Thank you for choosing FMF as your performance aftermarket exhaust. We have spent countless hours of R&D and testing to ensure you receive the highest quality product on the market today.

All FMF products are developed using the most current technology available for design and manufacturing. Every exhaust is made 100% at the Flying Machine Factory in Southern California. We use only the highest quality American materials for function and durability.

Since 1973, FMF has been bringing you the very best in bolt on performance. Our products are specifically engineered to broaden your existing powerband and give you an all around power increase with substantial weight savings. Bolt on FMF and ***FEEL THE POWER!***

Attention

This product is designed for closed course use only unless otherwise stated and not intended to meet emission regulations for use on public lands, roads or access routes – consult with local jurisdictions.

Please read all instructions thoroughly before installation. Failure to follow all installation instructions will void any warranty implied or otherwise. FMF Racing is not responsible for problems due to improper installation and/or improper use.

Before you begin installing this product, we recommend wearing safety glasses and mechanics gloves. You must know how to remove and replace your stock exhaust in order to install this FMF product otherwise have it installed by a professional mechanic. Keep all stock parts from your existing system as some components may be necessary to install your new FMF exhaust depending on the application.

Parts Supplied

(1) muffler:	042205-210
	042263-270
	042282-289
(2) 8x20mm bolt	920192

Tools Required

8, 10, 12mm wrenches
6mm Allen wrench
contact cleaner
high temp silicone
WD-40

Removal

1. Make sure engine is completely cool prior to installation and the vehicle is in a stable position.
2. Remove right side plastic panel to access the muffler.
3. Loosen the band clamp connecting the muffler midpipe to the header.
4. Remove the bolt attaching the midpipe to the subframe. For 2009 models, keep the bolt for later use..
5. While holding the muffler, loosen and remove the muffler mounting bolt.
6. Gently slide the muffler rearward to release it from the header. Use WD-40 in the midpipe/header junction to help ease removal.

Pre - Installation

7. Loosen the header flange hardware at the exhaust port to allow the header to rotate if necessary when mounting your new muffler.
8. Using contact cleaner, clean the section of the header where the midpipe connects and allow to dry. Apply a light bead of high temp silicone for an improved seal.

Installation

9. Slide the FMF midpipe onto the header. Wipe away any excess silicone.
10. For 2009 models, use the stock mid bolt removed in step #4 to attach the midpipe to the subframe. For other models, use one of the supplied 8x20mm bolts. Do not fully tighten at this time.
11. Apply a light bead of high temp silicone to the midpipe where the muffler connects for an improved seal.
12. Slide the FMF muffler onto the midpipe. Wipe away any excess silicone.
13. Use the other supplied bolt to mount the muffler. Do not fully tighten at this time.
14. Make sure the header and muffler are in a neutral position and not binding. Slowly tighten all mounting fasteners and clamps to manufacturer's specifications starting at the header flange and finishing at the rearmost muffler mount.
15. Inspect the complete exhaust to make sure there is no contact with the frame, shock spring, engine, body panels or any cables, hoses or wiring. The exhaust system should only be in contact with the exhaust port and mounting points. Confirm all controls operate in accordance with manufacturer's specifications.
16. Reinstall all body parts and panels to manufacturer's specifications.

Post - Installation

17. We recommend using high temp silicone for an improved seal. Please follow instructions for the silicone and allow sufficient time to cure before starting the engine.
18. All FMF exhaust products are designed to use stock fuel settings unless otherwise noted. There are too many variables to provide precise specifications; mainly altitude and temperature. If you are not capable of tuning the fuel settings yourself, please find a mechanic in your area.
19. Start the engine and bring to operating temperature. Check for exhaust leaks.
20. Allow the engine to cool completely and torque all mounting hardware to manufacturer's specifications.

Maintenance

To clean your FMF muffler, allow to cool and use mild soap and water. Do not spray water onto a hot exhaust. Mild soap and water is recommended on the muffler canister to reduce streaking and uneven discoloration. Dry completely with a soft cloth.

We recommend repacking your FMF muffler after every 20-30 hours of normal use with proper fuel settings (more frequently for less than optimal fuel settings). This will maintain peak performance and keep that race tone. Water will ruin packing. Cover the exhaust outlet when washing your vehicle. Repack your muffler if water enters the chamber and saturates the packing. We offer various repack kits to choose from. If the muffler has a spark arrestor screen, we recommend cleaning it gently with a wire brush after every 30 hours of use.

To repack the muffler, remove the allen screws from the front of the muffler. Do not remove the rear end cap. Grasping the midpipe, work the front end cap out of the canister. Use care not to damage or distort the shape of the canister or end cap. You may need a rubber or plastic mallet to lightly tap the front end cap out of the canister. Unwrap the packing from the core and discard. Clean the core with a wire brush then wrap with new packing and secure with a strip of 1/2" masking tape near each end of the core. Do not pack too tightly as this will hamper performance and increase sound level. Before reinstalling the inner core assembly, apply a thin bead of high temp silicone on the front endcap where it makes contact with the canister. Slide the inner core assembly into the canister making sure the perforated core is fully seated into the rear end cap. Wipe off any excess silicone. Reinstall the allen screws and tighten 1/4 turn after the screw contacts the canister. Allow sufficient time for the silicone to cure before starting the engine.

DISCLAIMER: All products manufactured and/or distributed by FMF Racing are a) intended for use on stock vehicles specific to the U.S. market; b) for closed course use only unless otherwise stated and c) not intended to meet emission regulations for use on public lands, roads or access routes – consult with local jurisdictions. FMF Racing makes no claims as to the products applicability, effectiveness or fitment on modified machines. FMF Racing is the sole determiner of abuse, misuse, installation errors and modifications. We assume no liability for any errors in listings, specifications, part numbers, prices or model applications. We reserve the right to change specifications, product descriptions, product quality, pricing and application at any time without notice and without further obligation. Buyer assumes all risk for any and all damage caused to themselves, a third party and/or property by virtue of failure of these products. By installing and/or using an FMF product, you hereby accept and understand these stated terms and conditions and have followed all instructional steps.

Rely only on high-grade motorcycle exhaust parts offered on our virtual shelves.