


2000-2003 CHEVY CORVETTE - V8 5.7L

Note: This Magnaflow Performance exhaust system requires professional welding for installation.

Warning: When working on under or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure safe work area. Serious injury or death could occur if safety measures are not followed.



Step 1: (Carefully read all instructions before installation) Begin removal of the OEM system by removing the (4) swaybar mounting bolts at the rear of the transmission. Do not discard these fasteners, as you will need them to re-mount the swaybar. Unbolt the mufflers from the catalytic converter extension pipes at the 2-bolt flanges. Remove the mufflers from the OEM rubber insulators (Removal of the passenger-side heat shield will aid in extraction of the muffler.) Do not damage the OEM rubber insulators, as they may be re-used to mount the new system.

Step 2: To remove the OEM H-pipe, you will need to cut the extensions in two places. Measuring from where the exhaust pipes are welded to the rear portion of the catalytic converters, the Driver's side pipe will be cut approximately 1" from the rear of the converter. The Passenger's side pipe will be cut approximately 3/4" from the rear of the converter. (See Diagram #2 and #3). Do not discard the the OEM H-Pipe hanger fasteners, as they will be re-used to mount the muffler assembly. Deburr the extensions you cut that are still on the vehicle to aid in installation of the muffler assembly.

Step 3: Begin installation of the new system by installing the threaded hangers and rubber insulators as shown in Diagram #4. Fit the tailpipes into place over the half-shafts, and fit the welded hangers into the rubber insulators mounted on the threaded hanger.

**MAGNAFLOW Performance Exhaust recommends professional installation on all their products*

Technical support: 1-800-959-9226 ext. 4500

MAGNAFLOW Performance Exhaust - 22961 Arroyo Vista - Rancho Santa Margarita, CA 92688

2000-2003 CHEVY CORVETTE - V8 5.7L

DIAGRAM #2




DIAGRAM #3



DIAGRAM #4



***MAGNAFLOW Performance Exhaust recommends professional installation on all their products**

Note: This Magnaflow Performance exhaust system requires professional welding for installation.

Warning: When working on under or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure safe work area. Serious injury or death could occur if safety measures are not followed.

Step 4: The new muffler assembly will need to be professionally welded to the OEM catalytic converter assemblies using the MIG or TIG process. Slide the inlets of the new muffler assembly over the catalytic converter extensions, and loosely re-install the OEM H-pipe hanger fasteners to help hold the muffler assembly in place. You can also loosely fasten the tailpipes to the muffler assembly using the supplied fasteners and gaskets. With all components mounted loosely, adjust the system for overall aesthetics and clearance of frame & bodywork. (MAGNAFLOW recommends at least 1/2" of clearance between the exhaust system and any body panels to prevent heat-related body damage or fire.) Now the muffler assembly can be tack-welded to the catalytic converter extensions. Once the muffler assembly is tack-welded to the converters, you will have to unbolt the catalytic converters from the exhaust manifolds and lower the entire exhaust system. This will allow enough space to properly finish-weld the muffler assembly to the catalytic converters. The catalytic converters can then be refitted to the exhaust manifolds (Refer to the car's shop manual for proper torque specifications).

Step 5: Once a final position has been chosen for the new system, evenly tighten all fasteners from front to rear. Inspect all fasteners after 25-50 miles of operation and retighten if necessary.

Technical support: 1-800-959-9226 ext. 4500

MAGNAFLOW Performance Exhaust - 22961 Arroyo Vista - Rancho Santa Margarita, CA 92688