



PART NUMBER: C151MRDS

PRODUCT: RDS BUMPER WITH
MULTIMOUNT AND SKID PLATE

APPLICATION: 2015 – C CHEVY
2500/3500

PARTS INCLUDED:	QTY
RDS Replacement Bumper	1
Skid Plate	1
Lower Skid Plate mounting Bracket	1
HARDWARE PACK:	1
3/8" X 1" Button Head Bolt	6
3/8" washer	6
3/8" Nut	6



INSTALLATION:

Step 1: Using a flat head screw driver, remove all 12 plastic retainers in the OEM plastic shroud and set aside.

Step 2: Use a 10mm socket and remove the four screws in top of grill. Gently pull out grill to remove. Start at top by pulling up and then out. Then pull out on bottom. Set aside.

Step 3: Using a 15mm socket, remove the 3 bolts from OEM bumper side brace. Set aside (both sides). Un plug OEM sensor/fog light harness. (If applicable)

Step 4: Using an 18mm socket, remove the four bolts holding on the OEM bumper. Set aside.

Step 5: Using an 18mm socket and wrench, remove OEM tow hook. (Both sides)

Step 6: Reinstall OEM grill and plastic shroud using OEM hardware.

Step 7: Using the OEM hardware, install the RDS bumper on to frame mounts. Do not fully tighten.

Step 8: Remove the lower A-arm nut from bolt. Do not remove bolt. (Both sides)

Step 9: Attach lower skid plate mounting bracket to the two OEM lower control arm bolts and tighten OEM nuts.



SKID PLATE
BRACKET

Step 10: Attach skid plate to lower mount and the two mounts in RDS bumper using the supplied 3/8" x 1" button head bolts, nuts, and washers. After bumper and skid plate is properly aligned, tighten all hardware. Your installation is complete.