

Warrior Products, Inc. 16850 SW Upper Boones Ferry Rd Ste. A Durham, OR 97224 Phone (888) 220-6861 Fax (503) 692-0364 sales@warriorproducts.com

SAFARI REAR LIGHT BAR

INSTALLATION INSTRUCTIONS WAR 843

'87 - '96 Wrangler & '97 & Up TJ

Read all instructions before proceeding.

Due to welding, handling, shipping, etc., the Light Bar legs may need to be "adjusted" slightly (bent in or out) to fit correctly. A small amount of twisting will not hurt the bar. Be careful not to scratch the paint as you install the legs.

- 1. Assemble the Light Bar by inserting lower mounting brackets onto the Light Bar hoop and inserting snapper pins to hold in place. For a more permanent install we recommend the use of the included _" x 1 _" bolts, washers, and Nyloc nuts. The light tabs should be facing rearward.
- 2. Position the light bar assembly so that both mounting brackets are even with the top of the body tub and the rear edge of the rear bracket is <u>approximately</u> 3/4" rearward from vertical body seam. The two pairs of horizontal and vertical holes should straddle the vertical seam, and the vertical holes should straddle the horizontal seam. Make sure the rear reinforcing plates fit next to the inside body seams. Mark where the holes are to be drilled and then remove the rear hoop.
- 3. Drill 3/8" holes where marked. Reinstall the rear Light Bar assembly. Install provided bolts through the body tub using the reinforcing plates on inside of the tub, and tighten loosely. Use of the bottom bolt on the rear mounting brackets is optional to provide extra rigidity and does require installation of the backing plate and nut from beneath the vehicle.
- **4.** Lights should be installed per the manufacturer's instructions.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS

QUALITY • INTEGRITY • INNOVATION • SERVICE