



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

ROCK CRAWLER BUMPER **WITH RECEIVER** INSTALLATION INSTRUCTIONS **WAR 575- 576- 577- 580**

1. Remove your existing bumper, or bumperettes, from your vehicle.
2. Install new bumper using the 7/16" lock nuts and washers provided. Washers should be placed between the nut and the frame. On some models the inside bolt holes are not drilled. You will need to align the bumper and drill holes 15/32" or $\frac{1}{2}$ ". The gas tank may or may not need to be lower to install the inside nuts on to the bolts. It is difficult but can be done with out lowering the tank.
3. After initial test drive, check all bolts for tightness. You should check all bolts for tightness each time before using the receiver hitch for towing.

Enjoy your new bumper!

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS