

# **YOSHIMURA**

RESEARCH&DEVELOPMENT OF AMERICA, INC.

5420 DANIELS STREET STE A, CHINO CA. 91710 · (800)634-9166 · (909)628-4722 · FACSIMILE (909)591-2198

www.yoshimura-rd.com

#### R77 TRI-OVAL PERFORMANCE EXHAUST SYSTEM

1314202	STAINLESS STEEL RACE SLIP-ON W/ CARBON FIBER R77		
1314205	STAINLESS STEEL RACE SLIP-ON W/ STAINLESS R77		
1314206	STAINLESS STEEL R77 RACE SLIP-ON W/ SS SLEEVE & TIP		
1314207	STAINLESS STEEL RACE SLIP-ON W/ TITANIUM R77		







Caution: Exhaust system can be extremely hot. Let motorcycle cool

down before beginning installation. Always wear hand and eye protection and take precautionary measures to avoid injury.

Note: Read through all instructions before beginning installation.

#### **Tools Needed:**

10mm and 12mm Sockets 3/8" Ratchet and Extension 3mm and 4mm Allen Wrench #2 Phillips Screwdriver Torque Wrench 3/16" Drill Bit Electric Drill Safety Glasses

### **Installation Steps:**

- 1. Remove passenger seat.
- 2. Remove driver seat.
- 3. Remove upper portion of rear tail. (See Fig. 1 &2)
  - -Remove 2 front plastic screw type rivets. (Fig. 1)
  - -Remove bolt. (Fig. 1)
  - -Remove push type rivet. (Fig. 2)
  - -Remove passenger seat lock cable.
  - -Remove tailpiece.
- 4. Loosen tailpipe clamps. (Fig. 3)
- 5. Remove left and right muffler heatshields. (Fig. 4)
- 6. Remove left muffler mount bolt then remove muffler. Repeat for right muffler. (Fig. 5)



Fig. 2



Fig. 3



Fia. 1



Fig. 4

- 7. Install Yoshimura collector clamp onto left Yoshimura tailpipe/muffler assembly.
- 8. Install left Yoshimura muffler assembly. Using stock bolt, tighten hand-tight. (Fig. 6)
- 9. Repeat steps for right Yoshimura muffler assembly.
- 10. Stand to the rear of the motorcycle and adjust mufflers and/or tailpipes to achieve desired fit, while checking all clearances.

Note: If insufficient clearances are found between bodywork and heatshields or tailpipes, loosen the midpipe clamp between the header and midpipe and adjust the orientation of the stock midpipe. Be sure to tighten the midpipe once orientation is set correctly.

- 11. Torque muffler mounting bolts to 16.5 lb-ft (2.3 kg-m)
- 12. Torque collector clamps to 16.5 lb-ft (2.3 kg-m)
- 13. Install left and right Yoshimura heatshields using supplied bolts. (Fig. 7)
- 14. Install tail fairing and seats using the reverse steps of removal.
- 15. It is recommended that the entire exhaust system be wiped down with rubbing alcohol to remove oil and fingerprints. This will help prevent tarnishing of the finish after the exhaust is heated up.
- 16. Before starting motorcycle, check for proper clearance between new exhaust system and motorcycle (i.e. Bodywork, swing-arm, etc.). If any problem is found, please carefully follow through the installation steps again. If problem still persists, please call Yoshimura tech. dept. at (800)634-9166 / in CA (909)628-4722

NOTE: After starting motorcycle, it is normal for new exhaust system and mufflers to emit smoke until oil residue burns off.



Fig. 5




Fig. 6



Fig. 7

Part List: Page 5

## #131420(2,5,6,7)



Parts Diagram

NO.	DESCRIPTION	QTY	PART #
1	Yoshimura Tail Pipe		
	Stainless Steel (Left Side)	1	1314-426
	Stainless Steel (Right Side)	1	1314-427
2	Muffler (Left)	1	
	R77 Muffler with Carbon Fiber Sleeve		1314202-LMA
	R77 Muffler with Stainless Steel Sleeve		1314205-LMA
	R77 Muffler with Titanium Sleeve		1314207-LMA
3	Muffler (Right)	1	
	R77 Muffler with Carbon Fiber Sleeve		1314202-RMA
	R77 Muffler with Stainless Steel Sleeve		1314205-RMA
	R77 Muffler with Titanium Sleeve		1314207-RMA
4	Medium Exhaust Spring	4	RACE-SPS-1
5	Left Heatshield	1	1314-HSL
6	Right Heatshield	1	1314-HSR
7	Heatshield Bolts	5	RC116HSB-BK
8	Collector Clamp	2	22059
**	Low Volume Insert	2	INS-04-K
**	Low Volume Insert for SRR77126W-SS	2	INS-03-K
**	Exhaust Spring Puller	1	ST-200
**	Yoshimura Sticker Kit Sheet	1	17029