



INSTALLATION INSTRUCTIONS

MAKE: Toyota

MODEL: Tacoma

YEAR: 2005-2011

ENGINE: V6-4.0L

ALSO FITS: Toyota FJ Cruiser 07-09; Toyota Tundra 05-06

Toyota 4Runner 03-09 with V6-4.0L engine

Twisted Steel Headers 48-46001



Parts Included:

- Bolts x6 (03-50401)
- Flange nut (03-50400)
- Exhaust Flange Gasket x3 (05-60366)
- Thermo Wrap Heat Tape x2 4" x 4" (05-40110)

Tools Needed:

- 10mm, 12mm & 14mm socket
- 3/8" drive ratchet
- 3/8" extention
- 14mm open wrench
- O2 sensor wrench
- Philips screwdriver

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

- Step 1:** Read Instructions prior to installation Secure vehicle on jack stands (Refer to your manual for specified jack stand positions).
- Step 2:** Remove the Right and Left side inner fender splash guard.
- Step 3:** un-plug O2 sensors on Y-pipe.
- Step 4:** Remove Y-pipe and right side catalytic converter.
- Step 5:** Unplug the O2 sensors on the right and left exhaust manifolds.
- Step 6:** Remove the 10mm bolt on the right side exhaust manifold securing the support bracket to the manifold.
- Step 7:** Loosen the x2 10mm bolts securing the exhaust manifold support bracket to engine block, so the bracket is free to move around but do not remove the bracket.
- Step 8:** Remove the right side exhaust manifold and set the manifold gasket aside as it will be re-used.
- Step 9:** Remove the 10mm bolt on the left side exhaust manifold securing the support bracket to the manifold.
- Step 10:** Loosen the x2 10mm bolts securing the exhaust manifold support bracket to engine block, so the bracket is free to move around but do not remove the bracket.
- Step 11:** Remove the left side exhaust manifold and set the manifold gasket aside as it will be reused.
- Step 12:** Remove the O2 sensor from the right side exhaust manifold and reinstall it on the right side aFe power header.
- Step 13:** Remove the O2 sensor from the left side exhaust manifold and reinstall it on the left side aFe power header.
- Step 14:** Install the the supplied thermo wrap heat tape to the wire harness next to the dip stick, and the other on the wire harness on frame rail next to the brake line.
- Step 15:** Inspect exhaust manifold gaskets. Replace if necessary.
- Step 16:** Install the right side aFe Power header back on the cylinder head using the original gaskets and 8mm nuts and tighten.
- Step 17:** Reinstall the exhaust support bracket to the header using the supplied 10mm nut and bolt make finger tight at this time. Tighten the (x2) 10mm bolts on the exhaust support bracket to engine block and tighten 10mm nut and bolt on the support bracket to the aFe power header.
- Step 18:** Remove the right side O2 sensor lead from the bracket on engine block so it will reach the O2 sensor connector and plug in O2 sensor.
- Step 19:** Install the left side aFe power header back on the cylinder head using the original 8mm nuts and tighten.
- Step 20:** Reinstall the exhaust support bracket to the header using the supplied 10mm nut and bolt make finger tight at this time. Tighten the (x2) 10mm bolts on the exhaust support bracket to engine block and tighten 10mm nut and bolt on the support bracket to the aFe power header.
- Step 21:** Remove the left side O2 sensor lead from the bracket on the engine block so it will reach O2 sensor connector and plug in O2 sensor.
- Step 22:** Reinstall the right side catalytic converter and Y-pipe using the supplied crush gaskets, 10mm nuts and bolts and tighten.
- Step 23:** Plug in O2 sensors on Y-pipe.
- Step 24:** Reinstall spring bolts on Y-pipe/exhaust system exhayst system and tighten.
- Step 25:** Reinstall inner fender splash guards.
- Step 26:** Reinstall the negative battery terminal.
- Step 27:** Re-check all your work, make sure there is adequate clearance between headers and wire harness.
- Step 28:** Remove vehicle off jack stands.
- Note:** It is normal for the aFe headers to emit smoke for the first few minutes upon initial start-up.



INSTALLATION INSTRUCTIONS

MAKE: Toyota
MODEL: Tacoma
YEAR: 2005-2014
ENGINE: V6-4.0L
Fits: 2 & 4 Wheel Drive

Y-Pipe 48-46006



Parts Included:

- (P/N: 05-60366) Exhaust Flange Gasket Set
- (P/N: 05-41061) 2-1/2" Band Clamp (x1)

Tools Needed:

- 12mm & 14mm socket
- 3/8" drive ratchet
- 3/8" extension
- 12mm, 14mm open end wrench
- O2 sensor wrench

CAUTION: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. aFe recommends professional installation on our products.

- Step 1: Read Instructions prior to installation Secure vehicle on jack stands (refer to your manual for specified jack stand positions)
- Step 2: Disconnect the battery before starting work on the exhaust system.
- Step 3: Remove the O2 sensors from the Y-pipe.
- Step 4: Remove the (x2) spring bolts on the Y-pipe to the exhaust system.
- Step 5: Remove Y-pipe and right side catalytic converter.
- Step 6: Install the Left side aFe power Y-pipe and clamp onto the Right side aFe power Y-pipe merge assembly.
- Step 7: Install the aFe power Y-pipe onto the OE manifolds using the supplied crush gaskets and original 10mm nuts and tighten.
- Step 8: Reinstall O2 sensors on Y-pipe.
- Step 9: Reinstall spring bolts and original donut gasket on Y-pipe to exhaust system and tighten.
- Step 10: Tighten clamp on aFe power Y-pipe.
- Step 11: Reconnect the battery.
- Step 12: Remove vehicle off jack stands.
- Step 13: Your installation is now complete. It is recommended to re-tighten all exhaust components after 50-100 miles.

Note: It is normal for the aFe power Y-pipe to emit smoke for the first few minutes upon initial start-up.