



Installation Instructions

Perma Shine Polished Stainless and Black Powder Coated Front DT Bumper with Hoop

**Part No. 8420-8620 76-06 Front Double Tube Bumper with Hoop
CJ7/Wrangler**



Installation:

- 1) Remove Torx bolts from front Bumper assembly. 2 located on each frame member on top of the Bumper.
- 2) Place Euroguard on top of the bumper and locate the holes over existing holes in the frame.
- 3) Replace Torx bolts tighten to 45lbs torque

Rampage Products
9225 Stellar Court Unit C, Corona, CA 92883-4919, U.S.A.
Phone: (951) 277-4949 Fax: (951) 277-2295 e-mail: info@rampageproducts.net
www.rampageproducts.net
Made in China