

Items Supplied >

- 1 - Front Exhaust
- 1 - Rear Exhaust
- 1 - Front Heat Shield w/clamps
- 1 - Rear Heat Shield w/clamps
- 1 - 6mm x 20mm Hex Bolt
- 1 - 8mm Hex Nut
- 1 - 1/4" Flat Washer
- 1 - 5/16" Flat Washer

Application >

HONDA VT1100 SHADOW 87-96

Instruction Manual >

1365SC

Page 1 of 1

PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.

1. Remove stock exhaust system.
2. Install front and rear exhaust and **FINGER TIGHTEN** all nuts and bolts.
3. Check for proper fit and alignment then, secure all nuts and bolts.
4. Install the front and rear full-length heat shields using the supplied hose clamps.

IMPORTANT: It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-1265.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*