

# DELTA<sup>®</sup>

## DELTA HEADLAMP KIT 1139 Series 5.75" Round Replacement For Earlier Model Show Cars, Domestic and Foreign P/N# 01-1139-50

### INSTALLATION INSTRUCTION

1. Remove your existing headlamps by unscrewing the bezel surrounding the headlamp.
2. Remove the retaining ring holding the headlamp.
3. Unplug the socket in the back of the headlamp element.
4. Plug in your DELTA headlamp element and install into the headlamp bucket using your existing screws
5. Tighten the bezel back on.



6. When installing High Beams in some car models, you may encounter difficulty with fitting your Delta headlamp in the old light bucket. This may happen when the bucket is not deep enough to allow free entry of protective rubber boot in the old bucket. You will need to drill 2 1/2" hole (as shown in the photo) to make room for the rubber boot. Also, note that your Delta high beam headlamps are equipped with H4, which have three prongs, while your existing headlamp plugs have only room for two prongs leaving your middle bulb prong (low beam) unused. If your headlights are not equipped with a H4 Adapter.

5 3/4" headlamps are E.C.E. Certified and currently being tested for D.O.T. compliance.

**NOTE: When installing, be sure rubber boot is snugly fitting over the reflector providing a good seal against moisture. In the event any moisture is trapped inside the headlight causing it to steam up, please follow these procedures: Peel back the rubber boot and carefully remove the bulb by releasing first the bulb spring. Allow vapor to escape by holding the headlight in sunlight or using a hair dryer. When completed, assemble the bulb and re-seal the boot around the reflector.**