



INSTALLATION INSTRUCTIONS

PART No.

FB23010

**Jeep® JK Wrangler
JK Rubicon Rock Sliders - 2DR**



VIDEO AVAILABLE



REQUIRED TOOLS

Ratchet wrench
18mm Socket
10mm Socket

KIT CONTAINS

M6 Clip-On Barrel Nut
M6 Hex Head Bolt
M6 Flat Washer
M6 Lock Washer

QTY

8
8
8
8

2301000

INSTALLATION INSTRUCTIONS

PART No.

FB23010

Jeep® JK Wrangler JK Rubicon Rock Sliders - 2DR

1) REMOVE FACTORY RAILS/GUARDS

Remove factory equipment if equipped.

2) INSTALL ROCK SLIDERS

Using an 18mm socket and ratchet, remove the body mount bolts. These bolts have a tendency to stop unthreading about halfway out. Simply apply some force to the large washer with your hand or a large open-ended wrench while turning the bolt to get it to release from the Jeep.



3) PREP YOUR SLIDER FOR INSTALLATION

Install the supplied barrel nuts to your sliders at each of the four (4) slotted holes (per side). Ensure the barrel nuts are installed as shown below.



4) INSTALL YOUR ROCK SLIDER

Lift your new rock sliders up to the Jeep. Insert your factory body mount bolts and tighten them enough to hold the slider to the body.

Using the M6 hardware, bolt your slider to the Jeep by inserting the hardware first through your Jeep's body and into the barrel nut.



5) TIGHTEN ALL HARDWARE.

6) REPEAT INSTALLATION PROCESS ON OTHER SIDE

7) ENJOY YOUR FISHBONE OFFROAD ROCK SLIDERS!