




Installation Instructions

Cat-Back Single Exhaust
Silverado / Sierra 1500 Truck
Regular Cab, Standard Bed, 4.8L-5.3L 2/4wd
Designed for vehicles equipped with Active Fuel Management
Part #615626



ITEM	PART	QUANTITY	DESCRIPTION
A	999700750S	1	3" Headpipe with ball seat flange
B	421887	1	Superflow Muffler
C	1136-700896S	1	3" Over axle Tailpipe
D	563-700432S	1	3" Exit Pipe
E	OHD300	3	3" Clamp
F	500379	1	4" Stainless Tip

Installation Instructions #615626


When installing this exhaust system make sure to use proper safety precautions. Use jack stands when working under the vehicle, set parking brake, block tires and use safety glasses and gloves. Allow exhaust to cool before attempting installation. Severe injury or burns could occur if safety measures are not taken.

SUGGESTED TOOLS: 1/2", 9/16", 15mm wrenches & sockets, WD-40, hacksaw, jack stands

1. Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual.



2. To remove stock exhaust, unclamp it at the connection behind the Y-pipe. Make sure to leave all rubber grommets in the factory location. You will re-use stock clamp. For easier removal of exhaust, cut behind the muffler. Use WD-40 to remove hangers from grommets.



5. Install the overaxle tailpipe #C onto the outlet of the muffler 1.5"-2" using clamp #E to secure pipe to muffler. Insert welded hanger into rubber grommet.



3. Install Headpipe # A onto the factory headpipe using the stock clamp. Do not tighten. Insert hanger into rubber grommet.



6. Slide exit pipe #D onto overaxle tailpipe using clamp #E to secure. Rotate exit pipe until it is at the correct angle for your truck. Insert welded hanger into rubber grommet.



4. Slide the muffler #B into the headpipe at least 1.5"-2". Use a jack stand to support the muffler. Use clamp #E to secure muffler assembly to the headpipe. The outlet of the muffler will be at approximately 11 o'clock. The muffler inlet is looking into the louvers. Do not tighten.

8. Install stainless steel tip. Clamp down. When you have everything in place, firmly tighten all bolts and clamps down securely. Use stainless steel cleaner and a Scotch Brite pad weekly to prevent tip from discoloration. Inspect all fasteners after 25-50 miles of operation and re-tighten as necessary.

GIBSON EXHAUST systems are designed on a factory stock vehicle
Any aftermarket products installed could increase the sound levels of the exhaust.

Make sure there is a 1" clearance from ALL rubber brake lines, shock boots, lines, tires, etc. to prevent heat related damage or fire.