


S6108P

04.5-07 DODGE 2500/3500 "600/610" 5.9L CUMMINS, CAT BACK, 4" SINGLE SIDE

MBRP
PERFORMANCE EXHAUST

March 20, 2017



PLEASE READ BEFORE STARTING INSTALLATION

MBRP Inc. has made every effort to ensure that all components of this system are of superior quality and properly packaged. It is the installer's responsibility to ensure that all components are present and fit together as shown. Please also ensure that all components are undamaged before removal of the factory exhaust. Finally, check that this system properly matches the make and model of the vehicle and will not interfere with previous or planned modifications.

Removal of stock system:

1. Apply a penetrating lubricant liberally to all exhaust fasteners, hangers and rubber insulators.
2. Remove the exhaust system from the rubber insulators and remove all of the clamps from the catalytic converter reward.
3. Separate the slip joint behind the muffler and remove the tail pipe. Then separate the slip joint located behind the catalytic converter and remove the muffler and extension pipe.

Installation of MBRP Inc. Performance Exhaust:

1. Install the Extension Pipe onto the catalytic converter. The Extension Pipe will require cutting to accommodate vehicles other than the Quad Cab long bed or Mega Cab truck. (Installation tip: Temporarily hang the Muffler in place using the three OEM rubber hangers and measure from the Muffler to the catalytic converter to determine the length required.)
2. Install the **Muffler** and **Hanger Band Clamp** over the **Extension Pipe** and into the OEM rubber hangers.
3. Install the **Hanger Band Clamp** onto the **Tail Pipe** and then install the **Tail Pipe** onto the **Over Axle Pipe**. Install the assembly from the rear of the truck, over the axle and attach to the outlet of the **Muffler**. Finish hanging the **Tail Pipe** by reattaching the rubber insulator.
4. Install the provided **Clamps** around pipes where needed. Adjust the **Tail Pipe** and check along the whole length of the exhaust system to ensure there is adequate clearance around the fuel and brake lines or any wiring. If any interference is detected relocate or adjust. Start at the front of the exhaust system and begin tightening all connections

Congratulations! You are ready to begin experiencing the improved power, sound and driving excitement of your MBRP Inc. performance exhaust system. We know you will enjoy your purchase.