



- H PIPE
- DRIVER SIDE EXTENSION PIPE
- 3. PASSENGER SIDE EXTENSION PIPE
- 4. DRIVER SIDE MUFFLER ASSEMBLY
- PASSENGER SIDE MUFFLER ASSEMBLY
- 6. 3" CLAMP [4 PCS]
- 7. TIP [2 PCS]

PLEASE READ BEFORE STARTING INSTALLATION

While MBRP Inc. has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following before removal of the factory exhaust:

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.

\$7241 © 1/18 PAGE 1 OF 3



Removal of Stock System



Figure 1

THAT CONTROL TO THE C

Figure 2

Figure 3



Figure 4

- 1. Apply a penetrating lubricant liberally to all exhaust fasteners, hangers and rubber insulators.
- 2. Remove the 2 piece undercar brace.

Refer to Figure 1.

3. Remove the M8 bolts from the mid hanger brackets and remove them from the vehicle. Retain these parts as they will be reused.

Refer to Figure 2.

4. Loosen both clamps ahead of the resonator, lift the lock tabs and slide the clamps rearward to disconnect the OEM catback exhaust. Use caution, The OEM catback is one piece and heavy.

Refer to Figure 3.

- 5. Remove the OEM catback by lowering the inlet end and sliding the assembly forward to remove it from the rear hangers. Remove the OEM clamps as they will be reused.
- 6. Unbolt and remove the rear hanger brackets. Retain these parts, they will be reused.

Installation of MBRP Inc. Performance Exhaust

1. Install the previously removed clamps onto the inlets of the **H Pipe** and install the assembly onto the vehicle with the flat side of the pipe support brackets facing the ground. Tighten the clamps enough to allow for adjustment while ensuring the **H Pipe** is level as viewed from the rear of the car.

Refer to Figures 4 and 5.

S7241 © 1/18 PAGE 2 OF 3





Figure 5



Figure 6



Figure 7



Figure 8

2. Install a **3" Clamp** onto each of the **H Pipe** outlets. Install the mid hanger bracket onto the **Driver Side Extension Pipe** before installing it onto the outlet of the **H Pipe**. Install the mid hanger bracket on the vehicle and secure with the previously removed M8 bolt. Tighten the **3" Clamp** enough to allow for pipe alignment.

Refer to Figure 6.

- 3. Install a **3"** Clamp onto the outlet of the **Driver Side** Extension Pipe. Install the rear hanger bracket onto the **Driver Side Muffler Assembly** before installing it onto the outlet of the **Driver Side Extension Pipe**. Secure the rear hanger bracket with the previously removed M8 bolt. Tighten the **3"** Clamp enough to allow for pipe alignment. **Refer to Figure 7.**
- 4. Repeat steps 2-3 for the passenger side components.
- 5. Install both **Tips** and tighten just enough to allow for alignment. **Refer to Figure 8.**
- 6. Install the undercar brace using the previously removed hardware.
- 7. Align the exhaust as required to center the **Tips** in the rear facia, and provide clearance around all other undercar components, then tighten all clamps.

Note; The mid hanger brackets can be used to help center the **Tips** in the Facia. Once all clamps are tight, adjust the mid hanger brackets to fine tune the placement of the **Tips** then tighten the M8 bolts.

8. Check along the whole length of the exhaust system to ensure that there is adequate clearance around fuel and brake lines or any other components. If any interference is detected relocate or adjust.

Congratulations! You are ready to begin experiencing the improved performance and driving pleasure of your MBRP Inc. performance exhaust system. We know you will enjoy your purchase.

\$7241 © 1/18 PAGE 3 OF 3