



MOUNTAIN OFF ROAD ENTERPRISES LLC.
P O BOX 690
DELTA, COLORADO 81416
877-533-7229
888-698-5337 fax

E-mail: info@mountainoffroad.com

www.mountainoffroad.com

INSTALLATION GUIDELINES for JM700 BombProof™ MOTORMOUNTS:

PLEASE READ THE TERMS-POLICIES ON PAGE 2

Thank you for purchasing M.O.R.E.™ motor mounts. They are designed to fit 1997-2006 Jeep® Wrangler vehicles when installing a **Generation III** Chevy V-8 engines. Please refer to the photo above for the proper frame location for the drivers side (DS) , and passengers side (PS). The block plates are the same for both sides. The JM700 mounts are designed to off-set the engine slightly to the passengers side of the Jeep® frame for front drive shaft clearance at the transmission. This means that you must use a transfer case with a drivers side front drive shaft, i.e. NP231, NP241 Etc. **These mounts will require the removal of the original frame mounts, frame modifications for A/C & minor firewall trimming. Your Jeep Wrangler should also have at least a 1" body lift and a minimum of a 4" suspension lift. Welding Required !**

We have spent countless hours test fitting the JM700 mounts, on several chassis with several engine/transmission combos and the JM700's fit them all with slight, or no modifications. Remember, you are performing a "conversion" and it will require some effort to complete the project.

INSTALLATION GUIDELINES: The stock motor mounts that are welded on the Jeep® frame must be completely removed. Torch, grind or Plasma cut them from the frame rail. Be careful not to cut into the frame! Grind any excess material from the frame so that the frame rails are smooth and have no ridges or slag remaining from the stock mounts.

The frame side of the JM700 mounts are designed to fit the frame in the location that we feel is the ideal location. These mounts are a weld on version so this location can be changed , that will be up to you to decide. Also the block brackets have 2 sets of holes that allow the height to be changed by 1" , You decide on which set you would like to use .

These mounts are designed to locate the engine in the proper location in relation to the firewall and radiator. We insist that the engine dictate where the rest of the drive train is located. There is only one perfect location. That is where we have located it. If installing a Chevy engine in your Jeep® for the first time, simply use the measurements (See pictures on page 2) to mount the JM700 motormounts to the frame by clamping (use some serious "C" clamps, or you can "tack" weld them for now) the frame mounts to the frame, bolting the block plates to the block, then install the engine and insert the 9/16" thru-bolts.

After the engine is bolted in place, then install the transmission and transfer case. When your conversion is completed and you are certain that everything is correct, then weld the motor mounts to the frame.

If you already have a Chevy engine converted into your Jeep®, and are replacing the conversion motor mounts with M.O.R.E.™ BombProof™ mounts, the holes may not line-up with where your engine is located, due to the infinite possibilities of engine locations. Don't panic! These mounts should still work! Simply move them forward or back to where your engine is located and weld the frame mounts to the frame.



Passenger side : Measure from the Upper Control arm bracket to the back side of the JM700 Mount. This measurement should be **3-15/16"**



Drivers side: Measure from the Upper Control arm bracket to the back side of the JM700 Mount. This measurement should be **6-1/8"**

TERMS-POLICIES:

FIT and TOLERANCES: All parts in M.O.R.E.™ products are the results of countless hours of research, testing, fitting and refining. Jeeps have a large tolerances from vehicle to vehicle. In addition to the factory tolerances, most people install other then factory equipment (aftermarket add-ons). M.O.R.E.™ has done the best job we can to insure that our parts fit with some of the possibilities. However, you may find it necessary to grind, elongate, bend, or force the parts you buy to fit on your rig. Be sure that you want to install them before you modify them. Please use common sense when installing these parts and let us know how we can improve them.

DAMAGE CLAIMS: All orders are carefully packed, however, mishandling by the carrier can result in damage. The carrier has the responsibility for the shipment from the time it leaves our warehouse until it is delivered to you. All claims for lost or damaged goods should be reported to the carrier, not to **M.O.R.E.™ LLC**.

RETURNS: No returns will be accepted without prior permission from **M.O.R.E.™ LLC**. After you receive a Return Goods Authorization (RGA) number, merchandise must be returned prepaid and insured. A claim must be made with in 30 days from receipt of merchandise. The original invoice or a copy with the RGA number written on must accompany all returns. A 20% restocking fee will be charged on all parts returned for credit or refund unless merchandise is proven to be defective or was shipped wrong by **M.O.R.E.™ LLC**. No merchandise will be issued credit or refund if it has been installed, modified, used in any way or is in unsalable condition.

WARRANTY: All merchandise is warranted to be free from defects in materials and workmanship prior to installation. Any alteration or improper use will void this warranty. Because all parts we sell are intended for use in heavy-duty applications it is not possible to warrantee or guarantee the performance of any items. **M.O.R.E.™ LLC** products and the products manufactured by others, which we sell may be subject to an infinite variety of conditions due to the manner in which they are used, serviced and/or installed. Purchasers and users of such products rely upon their own judgment as to the suitable use selection, service and installation of such products.

PRODUCT DISCLAIMER: Modification of your vehicle to enhance performance with parts sold by **M.O.R.E.™ LLC** may create a dangerous condition which could cause serious bodily injury, and the buyer hereby expressly assumes all risks associated with any such modifications. All parts sold by **M.O.R.E.™ LLC** are for racing or off road use only. Mountain Off Road Enterprises LLC. will not accept responsibility for personal injury or property damage arising from the failure of any parts manufactured or sold by **M.O.R.E.™ LLC**.

Specifications are subject to change without notice.

Jeep®, AMC®, CJ®, YJ®, TJ®, XJ®, Cherokee®, Wrangler®, are registered trademarks DaimlerChrysler.

M.O.R.E.™, BombProof™, S.R.S.™, SlipLoc™, DoubleJointed™, RockProof™, are trademarks used by **Mountain Off Road Enterprises, LLC**. The **M.O.R.E.™** logo, and this instruction sheet is copyright©, 1996-2008.

