

# POWERMADD®

## Yamaha Parking Brake Handguard Adaptor

### HARDWARE INCLUDED:

Item	Qty	Description
1	1	Bracket
2	2	Lock Nut
3	2	Screw

### TOOLS REQUIRED:

10mm Wrench  
4mm Allen

**Step 1:** Remove the two stock screws that mount the parking brake to the clutch perch. Using these two stock screws and the two lock nuts included with kit, mount the PowerMadd brake riser bracket to the Yamaha parking brake.

**Step 2:** Using the two shorter screws included with kit, mount the parking brake and bracket to the clutch perch.

