

HOOD PROTECTOR INSTALLATION INSTRUCTIONS

KIT CONTAINS:

HOOD PROTECTOR
6 SELF-TAPPING MOUNTING SCREWS
6 PLASTIC SHOULDER WASHERS

TOOLS NEEDED:

POWER DRILL WITH 3/32" INCH DRILL BIT
#2 PHILLIPS SCREWDRIVER
PENCIL
TAPE MEASURE

- 1** LIFT TRUCK HOOD, CAREFULLY REMOVE RUBBER SEAL AND HOLD PROTECTOR AGAINST THE UNDERSIDE OF TRUCK HOOD. CENTER THE HOOD PROTECTOR EQUALLY FROM THE EDGES OF THE TRUCK HOOD.

IMPORTANT! POSITION THE HOOD PROTECTOR SO THERE IS AT LEAST 3/4" CLEARANCE BETWEEN THE HOOD PROTECTOR AND THE HOOD ON EACH SIDE!

MARK THE CENTER OF EACH MOUNTING SLOT OF THE HOOD PROTECTOR WITH A PENCIL.

- 2** REMOVE THE HOOD PROTECTOR AND DRILL 3/32" HOLES AT EACH PENCIL MARK. USING THE PHILLIPS SCREWDRIVER AND A SCREW, THREAD THE HOLE WITH THE SCREW. DO THIS FOR EACH HOLE YOU HAVE DRILLED.
- 3** PUT THE HOOD PROTECTOR IN PLACE AGAIN USING A SHOULDER WASHER FOR EACH SCREW. SCREW THE HOOD PROTECTOR TO THE HOOD.
IMPORTANT! DO NOT OVER TIGHTEN THE SCREWS, THEY WILL STRIP THE THREADS IF TIGHTENED TOO MUCH.
REINSTALL RUBBER SEAL

- 4** CLOSE THE TRUCK HOOD SLOWLY TO MAKE SURE THERE IS CLEARANCE BETWEEN THE HOOD PROTECTOR AND THE TRUCK GRILLE. IF NECESSARY, ADJUST THE HOOD STOPS OR THE HOOD LOCK MECHANISM TO ALLOW FOR THE THICKNESS OF THE HOOD PROTECTOR

- 5** CLEANING YOUR HOOD PROTECTOR: USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!