



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

HALF DOORS
INSTALLATION INSTRUCTIONS
S916DOOR / 916DOOR
TJ WRANGLER 1997 - UP

Read all instructions before proceeding.

NOTE: Fits all applications where hard door striker pins and rotary paddle latch are used.

1. Assemble the door paddle handle, both sides, with bolt and nuts supplied.
2. On the inside of each door, install foam molding per Diagram "A".
3. Hang door on jeep and check for proper fit. Close door slowly onto paddle striker being sure that the paddle and striker line up correctly.

Enjoy your new Warrior half doors!

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS