



97-on Jeep® Wrangler Speaker Box Installation Instructions

READ AND UNDERSTAND INSTRUCTIONS BEFORE STARTING

NOTE: The maximum total depth of the speakers to be installed should not exceed 3 1/2".

Installation

1. Locate the two (2) included sheet metal screws used for installation and the sound deadening batting inside the speaker boxes.
2. Set the sheet metal screws aside for later use.
3. Pull the batting apart to fill the cavity of the speaker box as shown in Figure 1.




Figure 1

4. Run then speaker wire included with your speakers (not included with the speaker boxes) through the holes in the back. Position the speaker box in the vehicle where desired.
 5. Align and position the speaker box and mark the hole location using a pen or pencil.
 6. Drill a 1/8" pilot hole in the roll bar of the vehicle using the pre-drilled holes in the speaker boxes as a guide. Install the included sheet metal screws into the pilot holes as shown in Figure 2.
- NOTE: Repeat Steps 1-4 for the opposite side.
7. Install your speakers into the speaker boxes per the manufacturers instructions.



Figure 2



Installation Complete

Warranty
All Vertically Driven products are warranted to be free of defects in materials and workmanship for a period of thirty (30) days from consumer purchase date.

Made in USA