

RAM 2500 Factory Air Suspension Rear 1.5" Spacer Installation Instructions



- 1. Jack the truck up from the frame using a jack. The truck only needs to be lifted a few inches. Next, hit the dump button in the cab. Remove the nuts off the studs on the bottom of the bag. These studs will be removed and not reused. Pull the air bag down and rotate the bag 90 degrees so that you can get to the bottom of the air bag.
- 2. Locate the 1.5" riser (part# 18477) and fasten it to the bottom of the air bag with the 1/4-20x1" bolt. Torque to 30 ft/lbs.





3. Now that the spacer is installed on the air bag, locate the grade 8 1/4-20-1" bolts. Use these to bolt the spacer to the axle. Torque to 30 ft/lbs







4. Locate the sensor brackets (part# 18483 LH and 18483-1 RH). Remove the sensor from the bottom ball stud. Remove the ball stud from the axle mount. Locate the 6-12mm bolt and fasten the sensor bracket to the side of the axle mount. Use a marker to locate where to drill and tap the axle mount. Once you mark the axle mount, use a center punch and drill out the hole to 13/64". Next tap the hole to 1/4-20" Now you can fasten the sensor bracket in place with the 1/4-20x1" bolt and the 6 mm bolts. Place the OEM ball stud into the sensor bracket and reconnect the linkage.





5. Recheck all your bolts, remove the jack stands and start the vehicle. The install is complete.





QTY.	2	1	-							SHEET 1 OF 2
DESCRIPTION	1.5" Riser	.5" Lift Height Control Mount	1.5" Liff Height Control Mount	Project:	G5 Dodge (Air Ride)	Description:	1.5 un	SIZE DWG. NO.	⋖	
		1.5" Liff F	1.5" Liff F	Zach Beltz 2014 Project:				PROPRETARY AND CONFIDENTIAL	THE INFORMATION CONTAINED IN THE DRAWING IS THE SOLE PROPERTY OF KELDERMAN MFG, INC. ANY	ITAKI DE AS A WHOLE ITEN PERMESSON OF 3. INC. IS PROHISIED.
/BER		_	_	Design By:	94	Inventory	Run Qhy:	PROPRETARY	THE INFORMATIO DRAWING IS THE KELDERMAN	WITHOUT THE WR KELDERMAN MFC
PART NUMBER	18477	18483	18483-1	UNLESS OTHERWISE SPECIFIED:	DREDNINGS ARE IN INCHES TOURS NOTE THAT THE PROPERTY.	ANGULAR: MACH: 1 MIND:1	TWO PLACE DECIMAL 3,030	MATERIAL		
ITEM NO.	-	2	ဧ	INN	Dead	ANGU	MOM	MATERIAL	HSINIH	MDG#T