



READ INSTRUCTIONS - Failure to assemble cover properly will void warranty.



TruXedo, Inc.P.O. Box 1078, 2209 Kellen Gross Dr., Yankton, South Dakota 57078 Call Toll Free: 1-877-TRUXEDO (1-877-878-9336) Fax: (605) 664-9304







Place side rails on pickup bed rails.
Assemble clamps. Place rear clamps loosely over side rails & pickup bed rails. Insert side rail corner plugs into header:

NOTE:

Additional weather seal may be required for pickups with bed caps, tailgate protectors, or liners. Add weather seal if needed to seal appropriately.








TruXedo, Inc.


P.O. Box 1078, 2209 Kellen Gross Dr., Yankton, South Dakota 57078 Call Toll Free: 1-877-TRUXEDO (1-877-878-9336) Fax: (605) 664-9304
















TruXedo, Inc.P.O. Box 1078, 2209 Kellen Gross Dr., Yankton, South Dakota 57078 Call Toll Free: 1-877-TRUXEDO (1-877-878-9336) Fax: (605) 664-9304




Close cover:



Release safety straps, and unroll cover over pickup bed. Open tailgate.












- To prevent accidental release of tailgate header, ensure header is securely latched to side rails on both sides of pickup bed before driving vehicle.
- To prevent wind lift, secure loop and hook fasteners along entire length of both side rails before driving vehicle.

Adjust cover tension:


- A. To adjust tension, open cover slightly. Locate tension adjustment nut at tailgate end of each side rail. Turn nut to widen or reduce gap between header stop and tension adjustment base. Increasing width of gap will increase tension. Reducing gap width will reduce tension. A higher closing force will be required on initial installation. Turn tension adjustment nut to reduce gap between tension adjustment base. Lift cover Velcro® from side rail Velcro®. Repeat step 12. Cover will initially stretch making the next closing easier.
- **B.** Close cover and recheck tension. Repeat as required to achieve desired cover tension.
 - For best performance, and to protect your cover against wind wear, adjust tension regularly.
 - Check cover tension after installation, seasonally. and after extreme temperature changes.
 - Set tension during the warmest part of the day.




NOTE: Cover is designed to have optimal tension when there is a 1/4" gap between the header stop and the tension adjustment base.

Do not over tighten cover. If cover is too tight, it will not latch easily.


Open cover:







loop and hook fasteners prior to rolling up cover.




of pickup bed with both safety straps when cover is open.

IMPORTANT: Press down only on extreme corners of cover while opening cover, or opposite corner of cover may re-latch.

TruXedo, Inc.P.O. Box 1078, 2209 Kellen Gross Dr., Yankton, South Dakota 57078 Call Toll Free: 1-877-TRUXEDO (1-877-878-9336) Fax: (605) 664-9304





TruXedo, Inc.
P.O. Box 1078, 2209 Kellen Gross Dr., Yankton, South Dakota 57078 Call Toll Free: 1-877-TRUXEDO (1-877-878-9336) Fax: (605) 664-9304



FIVE YEAR WARRANTY

TruXedo, Inc. warrants that all new, unused products are free from defects in material and workmanship. This Five Year Limited Warranty is effective if the product is properly installed and used for the purpose intended. It applies to the original buyer only. TruXedo's obligation under this Warranty is limited to repairing, or at its option, replacing any part that is returned, transportation prepaid, to TruXedo, Inc., Yankton, South Dakota, if the product is, in our judgment, defective. All materials must be accompanied by an RMA (Returned Material Authorization) number requested by and authorized in advance of returning the materials. TruXedo, Inc. shall not be liable or responsible to supply or pay labor to replace any part found defective, nor shall it be liable for any damages of any kind or nature to person, product, or property.

There are no Warranties for used products or products that have been repaired, altered, modified, subjected to misuse, negligence, accident or ordinary wear and tear.

TruXedo, Inc. products are sold without any express warranty except as set forth above. TruXedo, Inc. is not obligated to honor warranty claims if Genuine TruXedo, Inc. parts are not utilized.

DIRECT ALL WARRANTY CLAIMS TO TRUXEDO, INC. AT 1-877-878-9336

A

WARNING

Tighten clamps securely on side rails before driving vehicle, to prevent cover from blowing off.

SAFETY INSTRUCTIONS

- 1. Do not place objects on or against cover or framework.
- 2. Do not tie cargo to TruXport framework.
- Never allow children or pets to occupy pickup box while cover is closed.
- 4. Cover is not airtight. Special care is required to keep cargo clean and dry.
- 5. Fabric cover won't prevent theft of contents inside truck box.
- 6. Cover must be rolled fully open and secured with safety straps when towing vehicle backwards.
- 7. Opened cover must be secured with both safety straps when driving vehicle.

OWNER/USER RESPONSIBILITIES

It is the responsibility of the owner/user to read this manual and comply with the operating procedures. The owner/user is also responsible for inspecting their TruXport® cover, and for having parts repaired or replaced when worn or damaged.

Failure to follow safety instructions and warning labels could result in failure of your cover system and/or personal injury.

MESSAGES TO INSTALLER

- Always wear safety glasses and/or other necessary protective equipment when installing your TruXport[®].
- These instructions are complete for most pickup models. Additional instructions are included, if required for your pickup. Please read entire manual before installing your TruXport®.

COVER MAINTENANCE

Vinyl cover can be hand washed with mild soap and water or cleaned in a car wash. Thoroughly rinse cover to remove any soap residue. Cover can be treated with any vinyl protectant made for tonneau covers.

Never use silicon, petroleum, or citrus based products on your tonneau cover.

Questions?

Call our friendly customer service staff at TruXedo. Inc. Toll Free:

1-877-878-9336

Mon - Fri 8 am - 5 pm CT

Register online at www.truxport.com or mail this form to: TruXedo, P.O. Box 1078, Yankton, SD 57078-1078	
Name:	
Address:	
City:	State: Zip:
Phone Number:	
Email Address:	
Date Purchased:	Product Purchased:
Price Paid:	TruXedo Lo Pro QT
Dealer Name:	O TruXedo Deuce
Pickup Make:	
Model:	O TruXport
Year:	Original TruXedo
	O TruXedoPlus

TruXedo, Inc.

P.O. Box 1078, 2209 Kellen Gross Dr., Yankton, South Dakota 57078 Call Toll Free: 1-877-TRUXEDO (1-877-878-9336) Fax: (605) 664-9304

