

18033 S. Santa Fe Ave Rancho Dominguez, CA 90221-5514 PH: 310-631-4363 FX: 310-900-5699 www.fmfracing.com tech@fmfracing.com [03-03 / #000351]

## SUZUKI RMX250 JETTING RECOMMENDATIONS

Here are our jetting suggestions for your **RMX250**. We've spent countless hours of testing to determine which settings work best when bolting on one of our pipes and silencers to a stock machine. These are recommendations only, based upon our testing at sea-level atmospheric pressure, a 65-80F degree ambient air temperature, a 32:1 fuel to oil mixing ratio on super unleaded pump fuel with a stock motor.

For some models we offer a Power Up jet kit for optimum tuning. Kits may include jets, needles and any necessary hardware and have been developed with the assistance of Dynojet.

There are too many variables outside of our control to give you an exact configuration that works perfectly under all conditions. Our recommendations are just that, a starting point to reference from. Higher elevations, high humidity, hotter temperatures are examples that will require leaner jetting. Colder temperatures are an example that will require richer jetting.

If you are unknowledgeable or don't feel comfortable tuning your machine yourself, find a mechanic in your area who is. FMF Racing is not responsible for problems derived from improper jetting and/or usage.

Always check that your jetting is correct when changing parts that could affect the intake system, exhaust system and any product or change that could alter fuel combustion in the cylinder (ie. aftermarket ignition module).

Check out our website www.fmfracing.com for additional information.

Use the following suggestions when using a FMF Fatty, Factory Fatty, Gnarly, Rev or SST exhaust pipe.

1998		1997		1996	
Main Jet	175	Main Jet	175	Main Jet	172
Pilot Jet	55	Pilot Jet	55	Pilot Jet	52
Needle	STOCK	Needle	STOCK	Needle	R1469NS
Clip Position	3RD	Clip Position	3RD	Clip Position	2ND
Air Screw	1.5 out	Air Screw	1.5 out	Air Screw	1.5 out
1995		1994		1993	
Main Jet	168	Main Jet	168	Main Jet	172
Pilot Jet	48	Pilot Jet	48	Pilot Jet	60
Needle	STOCK	Needle	STOCK	Needle	STOCK
Clip Position	3RD	Clip Position	3RD	Clip Position	3RD
Air Screw	1.5 out	Air Screw	1.5 out	Air Screw	1.5 out
1992		1991		1990-1989	
Main Jet	260	Main Jet	260	Main Jet	260
Pilot Jet	45	Pilot Jet	45	Pilot Jet	45
Needle	STOCK	Needle	STOCK	Needle	STOCK
Clip Position	3RD	Clip Position	3RD	Clip Position	3RD
Air Screw	1.5 out	Air Screw	1.5 out	Air Screw	1.5 out