

2007-12 Toyota Tundra 3" front lift kit 2WD & 4WD Part KT09125



www.Daystarproducts.com Tech Support Contact Info

Tech@DaystarWeb.com Phone: 623.907.0081

> Fax: 623.907.0088 841 South 71st Avenue Phoenix, AZ 85043

Instruction Sheet: P11258-02 2007 Daystar Products International Inc.

Revision: 2

Revision Date: 02/17/2014

Revised by: TY

Thank you for choosing Daystar Products

Daystar recommends a certified technician install this system. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post instructions checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating of the vehicle.

Please read all the instructions before beginning the installation. Check the kit hardware against the parts list. Be sure you have all the needed parts and understand where they go. If anything is missing, do not proceed with the installation, Call Daystar Products to obtain needed items. Torque specs are on page 5.

Product Use Information

As a general rule, the taller a vehicle is the easier it will roll. We strongly recommend, because of rollover possibility, that seat belts and shoulder harness be worn at all times. Avoid situations where a side rollover may occur.

Braking performance and capabilities are decreased when significantly large/heavier tires and wheels are used. Take this into consideration while driving, Also, speedometer recalibration is necessary when larger tires are installed.

Do not add, alter, or fabricate any factory or after-market parts which increase vehicle height over the intended height of the Daystar Product purchased. Mixing component brands, lifts, and/or combining body lift with suspension lift voids all warranties. Daystar makes no claims regarding lifting devices and excludes any and all implied claims. We will not be responsible for any products that is altered.

Notice to Dealer and Vehicle Owner

Any vehicle equipped with any Daystar Product must have the "Warning to driver" decal installed on the sun visor or dash. The decal is to act a constant reminder for whoever is operating the vehicle of its unique handling characteristics. IN-STALLING DEALER—Its is your responsibility to install the warning decal and forward these instructions on to the vehicle owner for review and to be kept in the vehicle for service life.

After installation occurs, a qualified alignment facility is required to align the vehicle to factory specs.

IMPORTANT NOTE: The advertised amount of lift that this kit provides and the thickness of the spacers supplied will not be the same! For example, a 2-1/2" lift may only have 1-1/2" thick spacers. The reason for the difference between the spacer thickness and the amount of lift has to do with suspension geometry. There is a ratio involved, and it is this ratio that determines the thickness of the spacers. Rest assured, installing the spacer supplied will result in the proper amount of lift out at the wheel.

Installation steps

- 1. The tools needed for installation are on the back cover. A list of parts in the kit are under the tool listing. Make sure you have all of the proper tools and understand these directions before proceeding.
- 2. Place the truck on a clean level surface and set the parking brake. Chock the rear wheels and using a floor jack raise the front of the truck and support the truck with approved jack stands under the frame rail behind the front wheels. NEVER WORK UNDER AND UNSUPPORTED VEHICLE. Using a 21mm deep well socket remove the front wheels.
- 3. Disconnect the front sway bar lower end links using a 19mm socket.





Loosen the two inner lower control arm pivot bolt using a 24 mm socket.



5. Place a floor jack under the lower control arm and support the arm, using a 14mm socket remove the upper strut nuts. Using a 22mm socket and wrench remove the lower strut bolt and nut.





6. Using a 24mm socket remove the lower ball joint bolts and lower the control arm down, to remove the strut assembly.





7. Put thread lock on the 8 (S11105) stud extenders inner and threads, and use a 5/8 wrench to install them on to the top of the strut plate, then install the Daystar strut spacer (M03800) over the stud extenders.







8. Install the strut assembly with the spacer installed back into the truck and put the 4 upper strut nuts on to hold the strut from falling out.





- 9. Raise the lower control arm so that the lower strut bolt/nut can be installed. Put thread lock on the 2 lower ball joint bolts.
- 10. Using a 24mm socket install the lower ball joint bolts into the control arm/knuckle assembly and tighten.



11. Using a 5/8 wrench tighten the upper strut nuts. With a 22mm socket and wrench tighten the lower strut bolt and nut.





12. Using a 24mm socket tighten the inner lower control arm bolts.



- 13. Reinstall the tires and tighten the lugs to 85 ft lbs. Jack up the truck and remove the jack stands. Lower Jeep back to the ground.
- 14. With the truck on the ground install the sway bar end-link. Using a 19mm socket tightened the bolt.





- 15. Check all bolts and nut that they are installed and tighten down.
- 16. Have a qualified wheel alignment center realign the front end to factory specs.
- 17. Have the headlight adjusted to proper settings.
- 18. Wheels must be retighten at 50 miles.
- 19. All components must be retighten at 500 miles and then at 3000 miles.
- 20. Install "Warning to driver" decal to sun visor.





STOCK TRUCK

Torque

LIFTED TRUCK DAYSTAR 3" LIFT

- Upper strut nuts, 33 ft lbs x 4 per side
- Lower strut bolt/nuts, 144 ft lbs x 1 per side
- Lower sway bar bolt, 89 ft lbs x 1 per side
- Lower ball joint bolts, 221 ft lbs x 2 per side



Daystar® Lifetime GoEverywhere Limited Warranty

Your Daystar® Comfort Ride or Budget Boost leveling kit is covered by the following *Go Everywhere* Lifetime Limited Warranty provided exclusively by Daystar Products International, Inc., 841 South 71st Ave., Phoenix, AZ 85043 ("Daystar").

What is Covered? Real Life Use, Off Road & On: Subject to the terms, exclusions and limitations herein, Daystar® warrants to the initial retail purchaser that your Comfort RideTM or Budget BoostTM leveling kit shall be free of defects in material and workmanship for so long as it is properly installed on a single vehicle owned by the initial retail Daystar® purchaser.

What is Not Covered? Your Vehicle & Parts Not Daystar's GoEverywhere:
Your Daystar Limited Warranty does not cover: (a.) damage to your vehicle, vehicle systems (ex. electronic stability control) other products, components or property not manufactured by Daystar to our exclusive GoEverywhere standards, (b.) customer choice of vehicle configuration/tire and wheel combinations contrary to Daystar® recommendations, warnings or applicable laws, (C.) Acts of God, weather, corrosion, accidents, theft, vandalism, negligent misuse or intentional damage, other exclusions under your OEM Limited Warranty.

Remedy Limited to Repair/Replacement. Get back on your favorite trail fast. The exclusive remedy provided hereunder shall, upon Daystar's inspection and option, be either repair or replacement of the Comfort RideTM or Budget BoostTM leveling kit or parts covered under this Limited Warranty. Call us and we will get you back wheelin' (623/907-0081). All labor, removal, shipping and installation costs are customer's responsibility.

Other Exclusions –Limitation of Damages - Your Rights Under State Law. Stuff Lawvers Sav.

At Daystar® we aren't big fans of lawyers, even ours. Still, he says our **Limited Warranty** has to include this stuff. In consideration of the purchase price paid, neither Daystar® nor any independent Daystar® distributor or repair person are responsible for any time loss, loss of vehicle use, rental costs, transportation, labor or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. No Daystar® employee or independent distributor is authorized to make any statement or representation altering the terms of Daystar's *GoEverywhere Lifetime Limited Warranty*. **Your exclusive remedy hereunder for covered parts is repair/replacement as described above.** This **Limited Warranty** gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability, fitness for a particular purpose or other implied warranty are limited to a period of four (4) years from date of initial retail purchase. Daystar® reserves the rights to: (a.) require invoice or other proof of purchase; (b.) make future revisions to these products and **Limited Warranty** without prior notice or obligation to upgrade your Daystar® product.

1

TOOLS NEEDED

- 14mm socket
- 19mm socket
- 22mm socket
- 24mm socket
- 5/8 wrench
- 14mm wrench
- 19mm wrench
- 22mm wrench
- 24mm wrench
- Lug nut socket

- 4 ton floor jack
- 2 Jack stands
- 2 Wheel chocks

BILL OF MATERIALS

- M03800 x 2 spacers
- BU76093 x 1 hardware
 - ♦ S11105 x 8 stud extenders
 - ♦ P11153 x 1 thread lock



