



INSTALLATION INSTRUCTIONS

57-3043

CHEVROLET/GMC

2004-06 COLORADO/CANYON HUMMER


2006 H3

L5-3.5L

NOTE: This kit was not designed to fit vehicles with a body lift.

TOOLS NEEDED:

- Flat blade screwdriver
- Ratchet
- Extension
- 7/32" socket
- 10mm socket
- 13mm socket
- 2.5mm allen wrench
- 10mm wrench
- 13mm wrench




PARTS LIST:

Description	Qty.	Part #
A	4	08610
B	1	08690
C	1	087031
D	1	087157
E	1	080021
F	1	08147
G	1	010059
H	2	08276
I	2	08239
J	2	07844
K	7	08275
L	4	07553
M	2	07793
N	1	09066
O	2	06530
P	1	08630
Q	1	102486
R	1	102488
S	1	074025
T	1	070602
U	3	07703
V	1	010060
W	1	21512
X	1	RF-1048
Y	1	08697
Z	1	102500
AA	1	08032


NOTE: FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS AND NOT USING THE PROVIDED HARDWARE MAY DAMAGE THE INTAKE TUBE, THROTTLE BODY, AND ENGINE.

TO START:


1. Turn the ignition OFF and disconnect the vehicle's negative battery cable.




2. Depress the locking clip on the mass air sensor electrical connection, and then separate the mass air sensor electrical connection.



3. Loosen the hose clamp that retains the stock intake tube to the resonator, and then remove the tube from the resonator as shown.




4. Loosen the two air box retaining bolts and one retaining nut.




5. Lift up the air box and remove it from the vehicle.

NOTE: K&N recommends that customers do not discard factory air intake.



6. On vehicles equipped with a fuel pressure regulator vent hose, disconnect the fuel pressure regulator vacuum hose from the fuel pressure regulator as shown.



7. Loosen the two bolts that retain the intake resonator to the engine, and then loosen the hose clamp at the throttle body.




8. Remove the intake resonator from the engine as shown.

NOTE: Disconnect the crankcase vent hose from the valve cover while removing the resonator from the engine.

NOTE: K&N recommends that customers do not discard factory air intake.



9. Install the silicone hose (08690) onto the throttle body and secure with the provided hose clamp as shown.



10. Install the "L" bracket (010060) onto the heat shield with the provided hardware as shown.



11. Install the edge trim onto the heat shield as shown.


NOTE: Start the 26" edge trim at the heat shield mounting bracket on the bottom of the heat shield. Some trimming may be necessary.



12. Install the edge trim onto the inner hole on the heat shield as shown. Trim if needed.



13. Install the "L" bracket (070602) onto the stock air box-mounting stud using the factory air box-retaining nut.




14. Install the heat shield into the vehicle using the hardware provided and the factory air box retaining nut.

NOTE: The front heat shield bracket will be secured to the front air box retaining bolt location.



15. Remove the mass air sensor from the stock air box as shown.



16. Apply provided gasket to mass air sensor as shown.



17. Install the mass air sensor assembly into the K&N intake tube using the provided spacers and button head allen bolts provided.



18. On vehicles equipped with a fuel pressure regulator vent hose, install the provided 1/4" npt vacuum fitting into the K&N intake tube as shown.



18a. On vehicles not equipped with a fuel pressure regulator vent hose, install the provided npt plug into the K&N intake tube as shown.



19. Install the mounting bracket onto the K&N intake tube with the provided hardware as shown.

NOTE: Do not completely tighten at this time.



20. Install the K&N intake tube into the silicone hose at the throttle body and through the heat shield, secure with the provided hose clamp.



21. Install the tube-mounting bracket onto the 6mm threaded stud protruding from the engine, then secure with the nut and washer provided.



22. On vehicles equipped with a fuel pressure regulator vent hose, install the provided 4mm vacuum hose onto the fuel pressure regulator, then onto the 1/4" npt vacuum fitting on the K&N intake tube.



23. Install the provided crankcase vent hose onto the valve cover, then onto the K&N intake tube as shown.



24. Install the filter adapter into the air filter and secure with the provided hose clamp.



25. Install the silicone hose (08630) onto the air filter assembly as shown.



26. Install the air filter assembly onto the K&N intake tube and secure with the provided hose clamp.



27. Reconnect the Mass Air sensor electrical connection.



28. Reconnect the vehicle's negative battery cable. Double check to make sure everything is tight and properly positioned before starting the vehicle.

29. The C.A.R.B. exemption sticker, (attached), must be visible under the hood so that an emissions inspector can see it when the vehicle is required to be tested for emissions. California requires testing every two years, other states may vary.

30. It will be necessary for all FIPK's to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void warranty.

ROAD TESTING:

1. Start the engine with the transmission in neutral or park, and the parking brake engaged. Listen for air leaks or odd noises. For air leaks secure hoses and connections. For odd noises, find cause and repair before proceeding. This kit will function identically to the factory system except for being louder and much more responsive.
2. Test drive the vehicle. Listen for odd noises or rattles and fix as necessary.
3. If road test is fine, you can now enjoy the added power and performance from your kit.
4. K&N suggests checking the Air filter element periodically for excessive dirt build-up. When the element becomes covered in dirt (or once a year), service it according to the instructions on the Recharger service kit, part number 99-5050 or 99-5000.