




## INSTALLATION INSTRUCTIONS

MAKE: Toyota  
MODEL: Tundra  
YEAR: 2010-2019  
ENGINE: V8-5.7L  
WHEELBASE: 145.7"

**Cat-Back**  
**49-46014-P (Polished tips)**  
**49-46014-B (Black tips)**



**Step 1: (Read Instructions prior to installation)** Remove your stock exhaust up to the catalytic converter from the rear of your truck working your way forward. Take caution not to damage the factory hardware and isolation mounts as they will be reused.

**It is recommended to not fully tighten the clamps until the entire system has been installed.**

**Step 2:** For faster installation spread the pieces of the exhaust along side of your vehicle according to the diagram shown.

**Step 3:** Install mid-pipes using factory bolts at flanges. Do not over tighten, now slip band clamps over the ends of the Muffler Assembly and slide on to the mid-pipes.

**Step 4:** Utilizing the factory isolation mounts now install the **right side** over-axle/tailpipe. Now tighten all of the band clamps from front to rear.

**Step 5:** Driver side (left) hanger bracket installation. Loosen the (2) outer rear frame. Locate and loosen/remove the (2) nuts from the outer rear frame tow hitch mount. Install the new tailpipe hanger bracket re-using the (2) factory nuts, tighten securely.

**Step 6:** Utilizing the new hanger bracket install the **left side** over-axle/tailpipe.

**Step 7:** Install both tips onto tailpipes. Position the tips with logos facing upwards. Tighten tips securely.

**Step 8:** Position the exhaust tailpipes to your desired position. Tighten all band clamps.

**Step 9:** Your installation is now complete. It is recommended to re-tighten all exhaust components after 50-100 miles.

### NOTES:

- aFe recommends that the tailpipe be at least 1/2"-1" away from any body panels to avoid heat related body damage. **Tighten and secure.**

**Caution:** Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on our products.**