



Bill Of Material		
Part No.	Description	Qty.
M03700	Spacer	2
S10292	10mm – 1.5 nut	12



INSTALLATION INSTRUCTIONS

1. Read complete instructions before beginning installation and verify the bill of material.
2. Ensure you have correct tools before beginning.
3. Raise vehicle to remove wheels.
4. Remove the tires/wheels and support the vehicle.
5. Disconnect the sway bar link and move sway bar out of way.
6. Disconnect the ABS line from the upper control arm and knuckle.
7. Remove upper strut tower nuts.
8. Remove the lower strut bolts.
9. Remove upper ball joint nut and separate it by hitting the side of the knuckle with a hammer.
10. The strut will drop down.
11. Pull the strut down so you can remove the strut from the vehicle.
12. You will have to cut the stock strut bolts. Put the stock nuts back on and use them as a guide to cut the studs.
13. After you cut the studs remove the nuts and install the lift spacer.
14. Use the new nuts provided in the kit to install spacer.
15. Reinstall the strut. You will have to rotate the strut 180°.
16. Install the lower bolts first. The lower is under load so you will have to run up the bolts. The holes will be off but will line up when you install the bolts. Tighten to 37 ft-lbs.
17. Install upper part of strut. Tighten to 37 ft-lbs.
18. Reinstall the lower ball joint and sway bar and ABS lines.
19. Do wheel alignment after installing kit
20. **RETORQUE ALL BOLTS AFTER 500 MILES.**



WARNING

This vehicle has been modified to enhance its performance. The steering, braking and handling of this vehicle will differ from standard passenger cars and trucks. This vehicle handles differently from an ordinary vehicle in driving conditions which may occur on streets, highways and off road. Avoid unnecessary abrupt maneuvers, sudden stops, sharp turns and other driving conditions that could cause loss of control, possibly leading to a roll over or other accident that could result in serious injury or death to driver and passengers. If larger tires are installed the speedometer will read lower than the vehicles actual speed.

DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

This kit should be installed by a professional mechanic

