



advanced FLOW engineering

Instruction Manual P/N: 77-46408

Make: **Audi** Model: **S3** Year: **2015-2019** Engine: **L4-2.0L Turbo**
Make: **VW** Model: **Golf R (MKVII)** Year: **2015-2019** Engine: **L4-2.0L Turbo**
NOTE: **Includes Quattro (AWD)**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

| Label | Qty. | Description | Part Number |
|-------|------|--------------------|-------------|
| A | 1 | Module | R77-46408 |
| B | 1 | LED Switch | 05-70029 |
| C | 2 | Velcro (2" Inches) | 05-01244 |
| D | 4 | Cable Ties | 05-60167 |

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.





SLEEP MODE

Figure A


Refer to Figure A for Step 1.

Step 1: Before installing your aFe module, you will have to place your vehicles ECU in sleep mode. In order to do this you will need to do the following:

- If the engine is cold, open the hood, close the doors lock the car and wait 30 seconds.
- If the engine is warm, open the hood, close the doors lock the car and wait 20 minutes.
- If the engine is warm and you can't wait 20 minutes, disconnect the battery.



Note: Do NOT open the doors or start the vehicle when one of the sensors is disconnected. This could create a check engine light.



Refer to Figure B for Steps 2-3.

Step 2: Remove engine cover to gain access to the MAP sensor.

Step 3: Locate the MAP and TMAP sensor. The MAP sensor is located on the front of the intake manifold. The TMAP sensor is located on the intercooler tube, underneath the AC compressor.



Refer to Figures C for Steps 4-5.

Step 4: Locate and disconnect the MAP sensor connector, by pressing down firmly on the locking tab and sliding the connector out of the sensor.

Step 5: Locate the MAP sensor jumper harness on the aFe POWER module. This is the harness with 3 wires on each connectors. Plug the female connector of the module into the MAP sensor, then take the male connector of the module and connect it to the female connector of the engine harness.




Figure D

Refer to Figure D for Step 6.

Step 6: Check with the picture to make sure the connectors are correctly connected.



Note: Make sure connections are fully engaged and not reversed. Usually, connectors make a snapping sound when fully engaged.

**Figure E****Refer to Figure E for Steps 7-8.**

Step 7: Disconnect the TMAP sensor, by pressing down firmly on the locking tab and sliding the connector out of the sensor.

Step 8: Locate the TMAP sensor jumper harness on the aFe module. This is the longer harness. Plug the female connector of the module into the stock TMAP sensor, then the male connector of the module into the female connector of the engine harness.



Figure F

Refer to Figure F for Step 9.

Step 9: Check with the picture to make sure the connectors are correctly connected.



Note: Make sure connections are fully engaged and not reversed. Usually, connectors make a snapping sound when fully engaged.



Figure G

Refer to Figure G for Steps 10-11.

Step 10: : Carefully route the switch cable behind steering wheel cover. Route the cable on the back of the switch to exit toward the top or bottom.

Step 11: Mount the Switch on an open, flat surface.

**Figure H****Refer to Figure G for Step 12.**

Step 12: Route the switch cable through firewall and into the engine bay. Follow the main harness through the grommet into the firewall. Plug the end of the cable to the module.

**Figure I****Refer to Figure I for Steps 13-14.**

Step 13: Mount the module in a safe location, such as on the frame, using the supplied Velcro strip. Then, secure the wires and module away from any extreme heat and moving parts, with the provided ties. Make sure all connections are secured and fully engaged.

Step 14: Reinstall the engine cover.



Figure J

Refer to Figure J for Step 15.

Step 15: When turning on the vehicle, the switch will go through the light. It will stop at its last setting.

The LED on the switch represents the different level of power.

- Green LED: Stock
- Yellow LED: Sport
- Orange LED: Sport+
- Red LED: Race

Use the grey button to select the desired setting. Power adjustments can be done at any moment.

Thank you for choosing aFe POWER!



Sprint Booster V3



P/N: 77-16408

Cold Air Intake System



P/N: 51-12672 (PDS)
54-12672 (P5R)

Air Intake System Cover



P/N: 54-12678-B

Momentum GT Intake



P/N: 51-76403 (PDS)
54-76403 (P5R)

aFe Lic. Plate Frame



P/N: 40-10097

Warranty

General Terms:

- aFe warrants their products to be free from manufacturer's defects due to workmanship and material.
- This warranty applies only to the original purchaser of the product and is non-transferrable.
- Proof of purchase of the aFe product is required for all warranty claims.
- Warranty is valid provided aFe instructions for installation and/or cleaning were properly followed.
- Proper maintenance with regular inspections of product is required to insure warranty coverage.
- Damage due to improper installation, abuse, unauthorized repair or alteration is not warranted.
- Incidental or consequential damages or cost, including installation and removal of part, incurred due to failure of aFe product is not covered under this warranty.
- All warranty is limited to the repair and/or replacement of the aFe part. To request Return Goods Authorization ("RGA"), email RGA@afepower.com or call (951)493-7100. Upon receipt of the RGA, you must return the product to the address provided in the RGA, freight prepaid and accompanied with a dated proof of purchase and the RGA. Upon receipt of the defective product and upon verification of proof of purchase, aFe will either repair or replace the defective product within a reasonable time, not to exceed thirty days.

| Product Category | P/N Prefix | Warranty duration |
|----------------------------------|--------------------------------|--------------------------|
| Direct OE Replacement Filters | 10, 11, 30, 31, 71, 73 | Life of the vehicle |
| Racing Filters | 18 | 1 year |
| Universal | 21, 24, 72, TF | 2 years |
| Air Intake Systems | 50, 51, 54, 55, 75, TR, TA, TL | 2 years |
| Exhaust Systems | 49 | 2 years |
| Intercoolers & Intercooler Tubes | 46-2 | 2 years |
| Intake Manifolds | 46-1 | 2 years |
| Differential Cover | 46-7 | Life of the vehicle |
| Exhaust Manifolds | 46 | 2 years |
| Throttle Body Spacers | 46-3 | 2 years |
| Fluid Filters | 44 | 90 days |
| Pre-Filters | 28 | 2 years |
| Heavy Duty OE Replacement | 70 | 2 years |
| PowerSports OE Replacement | 81, 87 | 2 years |
| PowerSports Intake Systems | 85 | 2 years |
| Tuners | 77 | 1 year |

No other warranty expressed or implied applies nor is any person or advanced FLOW engineering authorized to assume any other warranty. Some States do not allow the exclusion or limitation of incidental or consequential damages or do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
TEL: 951.493.7100 TECH: 951.493.7134
E-Mail: Tech@aFepower.com